



* Fuse recommended. Please verify directive for applicable installation regarding fuses

Date: 2016-04-18
Version: 1.0

Title: Liftgate DC/DC charger



General Information

Wiring:

Input: Up to 30th = AWG 8. Up to 60th = AWG 4
Output : AWG 10. Max 6th

Negative: Up to 30th = AWG 8. Up to 60th = AWG 4. Or
connect to groun/chassis.

Fuses:

Mount the fuses as close to each battery as possible.
Suitable fuse size: 30A

Temperature sensor:

Attach the temperature sensor onto the service battery.