



* Fuse recommended. Please verify directive for applicable installation regarding fuses

General Information

Starter battery:

Typically 55Ah to 100Ah for automotive applications.

A start battery should never be deeply discharged.

Solar panel:

Recommended output power range of 50W to 300W.
Output voltage may not exceed specified voltage limit of the D250SA. Please see instruction manual.
If possible, connect the negative wire directly to service battery (-).

Wiring:

Please see instruction manual for suitable dimensions.
Please verify directive for applicable installation regarding wiring.
A thick wire generate less voltage drop than a thinner wire at high current.

Service battery:

Size 40Ah to 300Ah

Batteries are connected in parallel to increase capacity (Ah).

Suitable deep cycle batteries should be used.

Alternator:

If the alternator is a "smart alternator" that can adjust voltage level by the engine control module or similar.
To get D250SA support a Smart alternator you connect the Red Smart Alternator cable to the ignition.

Charge voltage:

You can choose between 14.4V and 14.7V (AGM) on D250SA.
If you not connect the Black AGM cable you get 14.4V
If you connect the Black AGM cable to minus you get 14.7V.

D250SA:

Install according to instruction manual.

Temperature sensor:

Attach the temperature sensor onto the service battery.

Fuses:

If fuses are used, mount the fuses as close to each battery as possible.
Suitable fuse size:
D250SA: 30A
D250SA and SMARTPASS 120: 300A
Battery Monitor: 1A
Please verify directive for applicable installation regarding fuses.

System Monitor:

System Monitor continuously monitors voltage, current (charge and discharge) and calculates the charging status. System Monitor gives you a complete overview of your battery charge level and simply shows the percentage of charge remaining, as well as how many hours are left before the battery bank is empty.